Installation and operations manual Weather Alert Vibrator Model X67-V

General

The Silent Call Weather Alert Vibrator is designed to be used with the weather radio. It may function with other brands but correct operation cannot be guaranteed.

Operation

Plug the X67-V cord into the external output jack on the weather radio.

In operation, the X67-V will begin shaking whenever the weather radio goes into alarm. It will remain shaking until either the alert times out or until you cancel the alarm.

The weather radio also includes the ability to test the siren and the X67-V. On the weather radio, press the PROGRAM button. Then scroll down through the menu options until you reach "SIREN TEST (P8)". Press the ENTER button and the siren will sound and the X67-S will begin to flash. Press STOP again to cancel the test. Note that testing the siren and the X67-V only indicates that the X67-V is functional and is connected correctly. It does not test the S.A.M.E. programming. To program the WEATHER RADIO for your county or counties, please consult the WEATHER RADIO manual.

Battery Replacement

The Weather Alert Vibrator is operated on one 9 volt alkaline battery. To replace the battery, remove the battery door cover on the back of the case with a small flat object (i.e. small screw driver, paper clip, etc). Remove the dead battery by unsnapping it from the battery clip and replace with new battery.

To test the battery, push the button on the front of the case and the vibrator will shake if the battery is still good.

Technical Support

For technical support on this or any other Silent Call product, please feel free to contact us. You can reach us by phone at 800-572-5227 (voice or TTY) or by Email at support@silentcall.com

Limited Warranty

Your X67-V is warranted to be free of defects in material and workmanship for one year from the date of initial purchase. During that time, the unit will be repaired or replaced free of charge when shipped prepaid to Silent Call Communications. To obtain warranty service, contact Silent Call to obtain return materials authorization. This warranty is void if the defect is caused by customer abuse or neglect.

