



HA360SA2.1 – Security Alert Signaler

The HA360SA2.1 Security Alert will alert you to several different alerts when linked to the HA360 Main unit. The Main unit receives a wireless signal from the HA360DC and will flash a strobe, make a loud sound and vibrate a bed shaker. Once the Main unit receives the signal it will also send a signal to all HomeAware remote receivers.

The HA360SA2.1 has 5 different door alerts (DOOR, FTDOOR, BKDOOR, DOOR3, DOOR4), a burglar help alert (HELP) and a motion alert (MOTION). The HA360SA2.1 can connect to a NOAA weather radio (STORM), a home security (SECURIT). Every home security system is different, contact your provider for setup.

Installing Batteries

The HA360SA2.1 Security Alert comes with two #357 silver oxide long lasting batteries that need to be installed into the bottom of the unit. Once installed the red light should light when the button is pushed. If the light does not show, you may have the batteries in backwards.

Linking the HA360SA2.1 to the Main Unit

This procedure will link your HA360SA2.1 Security Alert to your HomeAware™ Main unit. The Main unit will also provide an alert to all HomeAware™ remote receivers. It is best to do the LINK procedure in the same room as close as possible to the HomeAware™ Main unit.

To link the HA360SA2.1 to your HomeAware™ Main unit follow the steps below.

1. Press SET UP button on the Main unit and the word LINK will be shown on the display, press Enter. LINK will begin blinking.
2. Remove the cover on the bottom of the HA360SA2.1 and press and release the small black button. PICK DEVICE will display on the screen, press the blue TONE button to select the alert you want displayed and press ENTER. Once you have made your selection DONE will flash on screen.

Switch Positions on the Back of the HA360SA2.1

There are three switch positions on the back of the unit.

1. N.Closed

Normally closed* - Is a contact that flows current in its normal state. Switching it on will open the contact, causing it to not allow current flow.

2. N.Open

Normally open* - Is a contact that does not flow current in its normal state. Switching it on will close the contact, causing it to allow current flow.

3. Door Chime

Is for when the barrel port is connected to the solenoid contacts of a door chime ringer. See note below.

NOTE: It is important that the switch not be on the open or closed positions if the HA360SA2.1 is being connected to the door chime ringer. That could damage the HA360SA2.1 if left this way for a long period of time. The HA360SA2.1 will continually to trigger if the doorbell button is a model that lights or glows.

Please check the user guide of the device you are connecting to the HA360SA2.1 for switch position. For further information on all HomeAware products please go to www.sonicalert.com

FCC Requirements

This device complies with part 15 of the FCC rules, and with RSS-210 of Industry Canada. Operation is subject to the following two conditions; (1) This device might not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC rules. These limits are designed to provide responsible protect against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions manual, may cause harmful interference to radio communications. However, there is no guarantee that interference will not interfere in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment on and off, the user is encouraged to try to correct the interference by one or more of the following measures:

- i. Reorient or relocate the receiving antenna.
- ii. Increase the separation between the equipment and receiver.
- iii. Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- iv. Consult the dealer or and experienced radio /TV technician for help

Modification not expressly approved by the manufacturer could void the user's authority to operate the equipment under FCC rules.

CANADIAN CERTIFICATION

This device complies with Industry Canada license exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

GENERAL DATA

UL listed Power Adaptor: AC100-240V~, 50/60Hz
Power Consumption: Adaptor Output: DC12V, 250mA

 <p>The Lightning flash and arrowhead within the triangle is a warning sign alerting you of dangerous voltage inside the product.</p>	<p>CAUTION: TO REDUCE THE RISK OF ELECTRICAL SHOCK, DO NOT REMOVE THE COVER (OR BACK) FROM THE PRODUCT. NO USER SERVICEABLE PARTS INSIDE. REFER SERVICING TO YOUR SONIC ALERT DEALER.</p>	 <p>The exclamation mark within the triangle is a warning sign alerting you of important instructions accompanying the product.</p>
--	--	--

WARNING: TO PREVENT FIRE OR SHOCK HAZARD, DO NOT EXPOSE THIS APPLIANCE TO RAIN OR MOISTURE.

The normal function of the product may be disturbed by Strong Electro Magnetic Interference. If so, simply reset the product to resume normal operation by following the instruction manual. In case the function could not resume, please use the product in other location.

- Attention should be drawn to the environmental aspects of battery disposal.



-  This indicating separate collection for electrical and electronic equipment.

SONIC ALERT'S 1 YEAR LIMITED WARRANTY

The HomeAware™ HA360SA2.1 is warranted against manufacturing defects in materials and workmanship for one (1) year from the date of purchase. Within this period Sonic Alert will repair or replace at our option the HomeAware™ HA360SA2.1 without charge for parts and labor.

Simply contact our customer service department to obtain an RMA (return authorization number) and instructions on how to process your product for return. Call 1-248-577-5400 or e-mail to customerservice@sonicalert.com. You'll need a copy of your receipt to process the return authorization.

Sonic Alert Warranty
Stephenson Hwy., Suite 323, Troy, MI USA



Made in China

www.SonicAlert.com 1-248-577-5400