


LA-278 Behind-the-Head Microphone

The LA-278 Behind-the-Head Microphone provides excellent audio quality with its directional capabilities. This microphone fits securely behind the head (below the hairline) and over the ears. This design allows the user to adjust the size to fit on the speaker's head comfortably for extended periods of time.



The LA-278 has a uni-directional pickup pattern. This means that the microphone's element must be oriented towards your mouth. It will not pick up audio very well from the side of the microphone. The main advantage of this type of microphone is that it helps minimize feedback and picks up less environmental noise.

Using the LA-278 Behind-the-Head Microphone

- Set the microphone sensitivity switch (located inside front cover of the LT-700 Portable FM Display Transmitter) to the MED position.
- Place the unit behind your head, below the hairline stretching the wire to fit comfortable over your ears. Position the microphone as close as possible to your mouth. For best results the mic element should be 1 to 2 inches from your mouth. This will help to ensure that the microphone picks up your voice rather than room noise.
- Connect the microphone plug firmly to the microphone jack on the LT-700.

